

FIG. 1


[illegible]

25 B

13

11

- You will be connected to the selected equipment.



The screenshot shows a window titled "Communication Menu" with a menu bar containing "File", "Edit", "View", and "Help". The main area displays icons for various communication tools arranged in a grid:

- ITS TESTING:** Represented by a folder icon.
- ARSB:** Represented by an icon of two people talking.
- Dial-Up Networking:** Represented by a computer monitor icon.
- FTP Server:** Represented by an icon of a person at a computer.
- Ftp:** Represented by an icon of a server rack.
- IMS 3270:** Represented by an icon of a person at a computer.
- LMOS:** Represented by an icon of two people talking.
- NMA:** Represented by an icon of a person at a computer.
- PMA:** Represented by an icon of a person at a computer.
- Ping:** Represented by a network diagram icon.
- Vendors:** Represented by a computer monitor icon.

A dashed line is drawn across the bottom right of the window, and a solid line points from the "Vendors" icon towards the bottom of the screen.



FIG. 2A

25C

DDM2000



Ddm2000

Follow the instruction at the beginning of this Job Aid before attaching your computer to any equipment.

To access the Lucent software:

1. Shut down programs.
2. Connect to A/C power.
3. From the Main Desktop double click on the DDM2000 folder.
4. Connect a serial cable from the serial port on the back of the computer to the interface on the Multiplexer.
5. Choose the appropriate type and version of software according to the Multiplexer.
6. Double click on the icon.
7. Depress the "Enter" key until a login prompt appears.
8. Login

This Folder has several versions of Lucent multiplexers provisioning software, including OC3's and OC12's.




FIG. 2B

[illegible]

The My Computer icon provides access to your computer's disk drive. Double-click on the My Computer icon to display a window with icons representing objects on your computer. You can maximize, restore, resize, and close this window as you can any other window.

Choose View, Toolbar to display a toolbar for use in the My Computer window. You can use this toolbar to navigate through the hierarchy and drives to which you have access. In addition, you have options that enable you to display the contents of your disk drives differently, depending upon your needs and preferences. For example, you can use the Small Icons option to display more icons on the screen, and you can use the Details option to display information about files, including file type and file size.




FIG. 3

-BOSTP

1. Use the instructions under to dial into BOSIP.
2. From the Main Desktop double click the Communications Menu.
3. From the Communications Menu, double click the LMOS icon. The following will be displayed.
4. From the toolbar click on "Connect".
5. Choose a connection. The Telnet window will appear.




FIG. 4

LMOS



There are two ways to access the LMOS database, Dial-Up and BOSIP.

1. From the Main Desktop double click the Communications Menu.
2. From the Communications Menu, double click the LMOS icon.
3. From the toolbar click on "Connect" the following connection menu will appear.



4. Choose the appropriate connection for your area. You can either double click the selection or highlight the connection and click the "OK" button. From this point the login in is the same.

FIG. 5




FIG. 6




FIG. 7




FIG. 8




FIG. 9




FIG. 10




FIG. 11